

This quick guide is a summary of the complete installation manual. The manual contains safety warnings and other explanations which must be taken into account. The most recent versions of this guide and the installation manual are available at the "Downloads" section on Erreka's website.
<http://www.erreka.com>

WARNING


The options and functions described in this guide apply for the firmware version indicated on the circuit. The firmware, as part of a process of continuous improvement, is subject to new functionalities or upgrades being included as a result of new versions which are not necessarily compatible with previous ones. For this reason, some options or functions may differ or be unavailable if your firmware is older than shown in this guide.

CAT800


Elements of the complete installation CAT800

Electrical wiring


- A: Main power supply
- B: Flashing light
- C: Photocells (Tx / Rx)
- D: Pushbutton/wall key



Assembly levels CAT800 (mm)



Manual operation CAT800



Unlocking for manual operation:


- Insert the key (1) and turn clockwise about 90°, without forcing it.
- Pull the release lever (2) until it is about 90°, without forcing it.

Motorised operation locking:

- Proceed in reverse order to release.
- Move the gate manually to interlock it in the operator mechanism.

Electrical wiring


- A: Main power supply
- B: Flashing light
- C: Photocells (Tx / Rx)
- D: Pushbutton/wall key




Assembly levels CAT1800 (mm)

Mechanical CTSR1800ES(M)

Magnetic CTSR1800EC(M)



Manual operation CAT1800



Unlocking for manual operation:

- Remove the cover protecting the lock.
- Insert the key (1) and turn clockwise about 90°, without forcing it.
- Pull the release lever (2) until it is about 90°, without forcing it.

Motorised operation locking:


- Proceed in reverse order to release.
- Move the gate manually to interlock it in the operator mechanism.
- Place the cover protecting the lock.

General connections

▲ Ensure the power supply is disconnected before making or changing the connection.

☞ When the connections are complete, return the control panel cover.

• The panel has a built-in radio receiver (RSD) to receive transmitter signals at 433.92MHz.



P287Z

LEDs:

- POWER Power connected
- LEARN Radio programming
- LED 1 "CLOSE" pushbutton enabled
- LED 2 "OPEN" pushbutton enabled
- LED 3 "STOP" pushbutton enabled
- LED 5 ST1 pushbutton enabled
- LED 6 ST2 pushbutton enabled
- LED 8 SG.C Photocell enabled
- LED 10 Loop detector (LOOP) enabled
- LED 11 Closing Limit Switch (FCC) enabled
- LED 13 Opening Limit Switch (FCA) enabled

Fuse

- F1 10A fuse

Connectors:

- CLOSE (1) Close Pushbutton
- OPEN (2) Open Pushbutton
- STOP (3) Stop Pushbutton
- COM (4) Pushbutton Common
- A.T. (5) Total Opening Pushbutton
- A.P. (6) Pedestrian Opening Pushbutton
- AUX (12VDC) (7) 12Vdc Auxiliaries supply
- SG.C (8) Closing safety device (photocell)
- COM/ GND (9) Safety Device Common / 12Vdc Auxiliaries supply mass (-)
- LOOP (10) Magnetic loop detector
- FCC (11) Closing Limit Switch
- COM (12) Limit Switch Common
- FCA (13) Opening Limit Switch

☞ **NOTE:** installation can be carried out in two different ways: either using the three "OPEN" (1), "CLOSE" (2) and "STOP" (3) connectors or using the "A.T." connector. When using the latter, it runs sequentially to avoid cyclical Open-Stop-Close orders.

Turning direction check

Turning direction: check operation using the OPEN and CLOSE connectors.

If turning direction is not correct, interchange the motor cables connected to cable connectors MOT1 and MOT2.


Total opening radio code programming (Roller Code transmitters)

☞ The radio card receives Standard Roller Code transmitters: IRIS (IR02, IR04) and LIRA (LR02). It does not receive fixed codes (LUNA/KUMA).

1 Connect the electrical power supply. Press S1 and keep it pressed down for around 2 seconds, until the "LEARN" LED comes on. Release S1 when "LEARN" comes on.

2 Press the transmitter button to be programmed while "LEARN" is on (any of the three transmitter channels can be used).


"LEARN" will go off after 2 seconds, indicating that programming is complete.



☞ Carry out the same process to programme more transmitters if required. The memory can be used with up to 25 transmitters.

Pedestrian opening radio code (Roller Code transmitters)


☞ Pedestrian opening is carried out with the fourth channel button, although it does not need to be programmed: when programming total opening (buttons 1, 2 or 3), number 4 is automatically assigned to pedestrian opening.



Deleting all the transmitters

1 Connect the electrical power supply.


2 Press S1 until the "LEARN" LED comes on, without releasing it. Keep S1 pressed down until "LEARN" goes off, and then release it. All the transmitters will be deleted.



Programming the run


- The operator automatically programmes the complete run during the first operation. To ensure programming is correct, the limit switches must be installed and correctly adjusted in their definitive positions. Maximum run: 12 m.
- Pedestrian opening is 1 metre. This distance is programmed as default and cannot be changed.

Function and mode selection using SW1



| DIP | Modes and functions | Option | Effect |
|---------------|-------------------------------------|-----------------------|------------------------------------------------------------------------------|
| DIP1 | Soft start-up | ON | no soft-startup |
| | | OFF | with soft-startup. |
| DIP2 | Limit Switches | ON | Limit Switches normally closed |
| | | OFF | Limit Switches normally open |
| DIP3 and DIP4 | Automatic mode or step-by-step mode | DIP3=OFF and DIP4=OFF | step-by-step mode (the gate only closes when receiving the key command) |
| | | DIP3=OFF and DIP4=ON | 12s automatic mode (the gate closes automatically after a 12-second standby) |
| | | DIP3=ON and DIP4=OFF | 24s automatic mode (the gate closes automatically after a 24-second standby) |
| | | DIP3=ON and DIP4=ON | 36s automatic mode (the gate closes automatically after a 36-second standby) |
| DIP5 | Encoder | ON | encoder disabled (does not perform soft-stop or obstacle detection) |
| | | OFF | encoder enabled |

Potentiometer adjustment



VR1: Sensitivity in detecting obstacles

The operator has an encoder to detect obstacles and prevent collisions. Sensitivity in detection can be adjusted using this potentiometer.

Turning the potentiometer clockwise decreases sensitivity; turning it anti-clockwise increases it.

VR2: Braking time

The motor is used to brake at the end of the operation, thus offsetting the inertia of the gate when braking. Adjust the potentiometer to ensure proper braking.

Turning the potentiometer clockwise increases the force; turning it anti-clockwise decreases it.

VR3: Soft-stop distance

Soft-stop adjustment, where the operator moves at slow speed before reaching the stopper.

Turning the potentiometer clockwise increases the distance; turning it anti-clockwise decreases it.

VR4: Operator force

Torque or force exerted by the operator during the operation. To ensure safety for people, adjust the force at the lowest value compatible with good operation of the facility.

Turning the potentiometer clockwise increases the force; turning it anti-clockwise decreases it.

▲ Torque adjustment, respecting the maximum closing forces set out in Standard EN12453:2000. Make the readings as described in Standard EN 12445:2000.